

Microphone turns your microphone on and off.



Volume + and - adjusts the system volume.



OK/Select: Press the key to confirm

Phone book: Press the Phone Book key to display the local directory.



Press **Call** to place a call.




Clear: Press the Clear key to remove characters in a text field.



Press and hold

Use **Zoom + and -** to zoom the camera in and out.



Press the **Layout** key to display the Layout menu, then select a view in the menu.



Press the **End call/Standby** key to end a call, or when idle, press and hold the key to go into standby mode.



Alphanumeric keypad: Use the keypad to enter letters or numbers, similar to a cellular phone key pad

- **0-9, a-z, period (.), @, space,*:** Press a key repeatedly to toggle between the options displayed on each key.

- **abc/123 #:** Press the # key to toggle between touch tones mode (long press), lower case characters and numbers.

Press and hold

Use the **pound key** to enter touch tone (DTMF) mode (in a call). Press **OK** when done.

abc/123: When entering text, change between capital

Waking up the system

Grab the remote control and make sure your hand touches the rubber line sensors going along both sides of the remote control.

or: Touch **any key** on the remote control.

